

How to clean your RHINO device

Unless otherwise indicated by the product user guide, you may clean your RHINO device as follows:

DO: Use a dampened, lint-free cloth and wipe gently over all surfaces

DO: Wipe down the unit as frequently as is demanded for its use case

DO NOT: Use harsh chemicals or detergents

DO NOT: Submerge in water

DO NOT: Use abrasive materials

DO NOT: Block ports, vents or other in/outlets

Your RHINO device may have an antibacterial solution for healthcare settings, and due care should be taken not to remove this.

NB: If chemicals are used to wipe down the screen on units not coated with a chemical resistant solution, the oleophobic coating will be removed and fingerprints will most certainly become more pronounced during use. This is not covered under warranty, and a oleophobic solution may need to be purchased and applied to impacted devices in order to restore resistance to natural oils.